



- D1 Red LED - Junque Box
- J1, J2 Stereo 1/8" jacks - Digikey
- J3 6 pin Mini-din plug PC Mouse cable - see IC-706IIg manual
- J4 9 Pin D-Sub Female - PC serial cable
- K1 12v reed relay - Radio Shack
- R1 10,000 ohm pot - Volume knob from old am/fm radio
- S1 Small On/Off toggle - Hamfest
- T1, T2 600 ohm 1:1 - Scavenged from PC Modem cards
- Enclosure - Altoids box
- Point to point wired on perfboard

N8YSZ Soundcard Interface	
Revision: 1.0	Date: 20051004
Author: n8ysz@brauhaus.org	